

Philips
Lid for water
container

- Café Gourmet
- Black

CP9033



Covers the coffee maker water compartment

Go to the Specifications Tab to check your matchin

Ensure clean water in the water tank of your drip filter coffee maker. For filling the water compartment you don't need to remove the whole lid. Raising the flexible part only is sufficient.

Ease of using Philips spare parts

- Renew your product with original Philips parts

PHILIPS

Specifications

Replaceable part

- Fits product types :: HD5407/60

Highlights

Easy replacement

From time to time your product needs a facelift but it was never so easy like with Philips consumer replacement parts to renew your product. This all with guaranteed Philips quality and 1:1 exchange.



Issue date 2015-05-20

Version: 1.0.1

© 2015 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com